

2012 Chevrolet/GMC Express/Savana CNG

Compressed Natural Gas Supplement

Instruments and Controls	4-1
Warning Lights, Gauges, and Indicators	4-1
Driving and Operating	8-1
Driving Information	8-1
Starting and Operating	8-1
Fuel	8-2
Towing	8-7

Vehicle Care	9-1
General Information	9-1
Vehicle Checks	9-2
Wheels and Tires	9-5
Jump Starting	9-5
Towing	9-5
Appearance Care	9-6

Service and Maintenance ...	10-1
Maintenance Schedule	10-1
Maintenance Records	10-3
Technical Data	11-1
Vehicle Data	11-2
Index	i-1

ii Introduction



The names, logos, emblems, slogans, vehicle model names, and vehicle body designs appearing in this supplement including, but not limited to, GM, the GM logo,

CHEVROLET, the CHEVROLET Emblem, GMC, the GMC Truck Emblem, SAVANA, and EXPRESS are trademarks and/or service marks of General Motors LLC, its subsidiaries, affiliates, or licensors.

This vehicle only operates on Compressed Natural Gas (CNG). It will not operate on gasoline, diesel, or Liquefied Petroleum Gas (LPG) fuel.

Keep this manual in the vehicle for quick reference.

Canadian Vehicle Owners

Propriétaires Canadiens

A French language copy of this manual can be obtained from your dealer or from:

On peut obtenir un exemplaire de ce guide en français auprès du concessionnaire ou à l'adresse suivante:

Helm, Incorporated
P.O. Box 07130
Detroit, MI 48207

1-800-551-4123
Numéro de poste 6438 de
langue française
www.helminc.com

Using this Supplement

This supplement contains information specific to the unique components of the vehicle. It does not explain everything you need to know about the vehicle. Read this supplement along with the owner manual to learn about the vehicle's features and controls.

Index

A good place to look for what you need is the Index in back of this supplement. It is an alphabetical list of what is in the supplement, and the page number where you will find it.



NOTES

[illegible]


Instruments and Controls

Warning Lights, Gauges, and Indicators

Fuel Gauge	4-1
Malfunction Indicator Lamp ...	4-2

Warning Lights, Gauges, and Indicators

Fuel Gauge



The fuel gauge, when the ignition is on, indicates how much fuel is left in the vehicle fuel tank.

An arrow on the fuel gauge indicates the side of the vehicle the fuel door is on.

The fuel gauge has been calibrated to display full at approximately 24 800 kPa (3,600 psi) and empty at approximately 2 758 kPa (400 psi).

When the low fuel warning indicator flashes, fill the tank as soon as possible.

Compressed Natural Gas (CNG) quantity is affected by changes in fuel temperature and fuel pressure.

See *Filling the Tank* on page 8-3 for more information.

Malfunction Indicator Lamp

This vehicle has been specifically designed to illuminate this indicator when emissions exceed acceptable levels while operating on natural gas fuel.

The malfunction indicator lamp comes on to indicate that there is a problem and service is required. Malfunctions often will be indicated by the system before any problem is apparent. This system is also designed to assist the service technician in correctly diagnosing any malfunction.

Notice: If the vehicle is continually driven with this light on, the emission controls might not work as well, the vehicle fuel economy might not be as good, and the engine might not run as smoothly. This could lead to costly repairs that might not be covered by the vehicle warranty.

This light should come on, as a check to show you it is working, when the ignition is on and the engine is not running.

See the owner manual for more information.

Driving and Operating

Driving Information

Vehicle Load Limits 8-1

Starting and Operating

Starting the Engine 8-1

Fuel

Fuel 8-2

Filling the Tank 8-3

Fuel System Leak 8-5

Towing

Trailer Towing 8-7

Driving Information

Vehicle Load Limits

Notice: Loose items stored in the cargo area may damage the fuel tank and fuel system components. Secure all items in the cargo area to avoid shifting and any damage to the fuel tank and fuel tank components.

Starting and Operating

Starting the Engine

Starting the engine in a CNG vehicle is similar to starting a gasoline engine. See “Starting the Engine” in the owner manual.

Cold Weather Starting

If the outside temperature is below -20°C (-4°F), the engine may be harder to start, or may not start until temperatures increases.

Using the engine heater may make it easier to start. See Engine Heater in the owner manual for more information.

8-2 Driving and Operating

High Altitude Cold Starting

An engine is harder to start in cold weather. The thinner air found above 1,600 m (5,000 ft) also makes the vehicle harder to start. The unique properties of CNG makes it even more difficult or impossible to start at high altitudes if temperatures drop below -16°C (4°F). When starting the vehicle in cold weather at high altitudes:

- Use the engine heater. See Engine Heater in the owner manual for more information.
- Turn off all electrical accessories.
- Do not hold the ignition switch in START for more than 15 seconds.

Fuel

This vehicle is designed to operate on Compressed Natural Gas (CNG). The general marketplace fuel quality of Compressed Natural Gas (for motor vehicles) in the state of California shall be in compliance with Title 13 California Code of Regulations, Section 2292.5. The remaining USA States and Canada, do not employ regulated fuel quality standards for general marketplace vehicle usage. With this, a recommended practice as outlined by the provisions contained in SAE J1616 "Recommended Practice for Compressed Natural Gas Vehicle Fuel" is intended to protect the interior surface of the fuel container and other vehicle fuel system components.

If a fuel is used that does not meet these regulations/provisions, there may be a decrease in engine power and the emission controls can be damaged.


The main component of CNG is methane, a highly flammable, colorless gas. An odorant has been added for detection through smell. The smell is similar to that of rotten eggs. CNG used in vehicles is a similar type gas that is delivered to homes for domestic use. The CNG in the vehicle is stored under high pressure (maximum 24 800 kPa/ 3,600 psi). The CNG system in the vehicle, including the tanks and tubing, has been designed to hold gas at this pressure. It has also been tested for safety. Gas should never be smelled and a hissing sound should not be heard, unless refueling is being done. If gas is smelled or a hissing sound is heard,

at any other time, shut down the vehicle and have it serviced. It may be possible to hear the fuel flowing while the engine is running if standing close to the pipework or various fuel system components (regulator, filter). This is normal and should not be confused with a hissing sound at fittings that may indicate a fuel leak. Follow the instructions under *Fuel System Leak* on page 8-5.

Filling the Tank

WARNING

CNG is flammable and highly explosive. You could be killed or seriously injured if leaking natural gas is ignited. If you suspect a leak, have the vehicle immediately inspected and repaired by an authorized GM dealer.



The fill valve is behind a hinged fuel door on the driver side.

There is an identifying blue diamond-shaped CNG label on the right rear cargo door. Do not remove this label. This label is necessary for compliance with NFPA-52 regulations and insuring the vehicle. Driving without this label may violate the laws or regulations in some states. Replacement labels can be ordered from your dealer.

Refueling Procedure

There are two methods of refueling, fast filling or slow filling. Fast filling is normally used in fuel stations for natural gas vehicles. It takes about six to eight minutes to fill up the fuel tanks. Slow filling is done with a vehicle refueling appliance or a time-fill post provided by the fleet operator. Refueling time varies depending upon the refueling system used — consult with the refueling station attendant or system provider. Always observe all safety recommendations and operating instructions on the refueling equipment. When refueling, use a fuel fill nozzle that complies with ANSI/CSA-NGV 1-2006 standards. Nozzles are designed according to their maximum fill pressure: P30 (blue handle) for 20 684 kPa (3,000 psi) and P36 (yellow handle) for 24 800 kPa (3,600 psi).

8-4 Driving and Operating


The maximum fill pressure is 24 800 kPa (3,600 psi). Refuel with a yellow P36 nozzle where available. Using a blue P30 nozzle will fill the tank to approximately 7/8 on the fuel gauge.

WARNING

Attempting to fill a CNG fuel system that has a missing or damaged O-ring is dangerous. Natural gas can leak. If the natural gas is ignited, you or others could be injured. Replace the O-ring before filling the tank.

The refueling fill valve on the vehicle is located in the same location as was provided originally for gasoline refueling. Put the vehicle into P (Park) and turn off the engine prior to refueling. Remove the dust cap from the receptacle, clean off any dirt or debris on the

receptacle, and follow the refueling instructions on the pump or provided by the station operator.



If fuel or vapor is heard or seen leaking from the nozzle-fill valve connection, stop refueling immediately. Dirt or other debris may be preventing a positive connection. Turn off the refueling dispenser, disconnect the nozzle, reconnect it to the fill valve, and begin refueling again. If it continues to leak, have an authorized dealer

inspect the sealing O-ring in the fill valve. It may be missing, damaged, or worn. Spare O-rings designed for use with CNG are included with the vehicle. See an authorized GM dealer for additional O-rings.

To replace the fill valve O-ring:

1. Carefully remove the O-ring from the groove in the fill valve. A small flat-blade or pointed tool can be used.
2. Make sure the groove is clean and free of dirt and debris.
3. Install the new O-ring in the groove in the fill valve. Make sure the O-ring is properly seated in the groove.

Refueling will stop automatically when the tank is full. To disconnect the vehicle from the refueling station, remove the nozzle from the fill valve. A hissing sound may be heard as a small amount of natural gas escapes. This is normal.

If dirt or other debris is adhering to the inside of the fuel fill valve, gas may leak out after refueling. If you need to add more fuel, do the refueling procedure again.

Put the fill valve dust cap on securely and close the fuel filler door.

Refueling Station Information

For up-to-date information on public-access CNG station locations and prices, and to view or add user comments, please visit:

www.cngprices.com and
www.cngchat.com

Public and private CNG stations may also be found at the following federal government website:

<http://www.afdc.energy.gov/afdc/locator/stations/>

Fuel System Leak

WARNING



If you smell a persistent natural gas odor or hear a continual hissing sound, there could be a natural gas leak. If the natural gas is ignited, you or others could be injured. Do not start the engine or drive the vehicle. Have the vehicle towed to an authorized GM dealer for service.

A slight natural gas odor may be detected for a few moments after refueling. This is normal. You should not be able to smell natural gas at any other time. If you do, or if you hear a hissing sound, the fuel system may have a leak.

If natural gas is smelled or a hissing sound is heard:

1. Park the vehicle in a well-ventilated area and apply the parking brake. Keep heat, sparks, and flame away. Open all the vehicle doors for ventilation.
2. Turn the ignition to LOCK/OFF.

8-6 Driving and Operating



3. The manual shutoff valve is on the inner side of the driver side frame rail halfway between the front and rear tires.

A label is on the outside of the vehicle above the manual shutoff valve. Do not remove this label.

Turn the lever one-quarter turn clockwise to turn off.

Do not drive the vehicle. The vehicle should be towed to an authorized GM dealer.

Towing

Trailer Towing



WARNING

The trailer hitch protects the CNG tank in a crash and from road hazards. Damage may result in a rupture or explosion of the CNG tank. You or others could be injured or even killed. If the trailer hitch must be removed for any reason, e.g, tank inspection or vehicle repair, always reinstall the trailer hitch before operating the vehicle.

The compressed natural gas system adds approximately 363 kg (800 lbs) of weight to the vehicle. This must be included when determining the maximum load and trailer towing capacity for the vehicle as described in the owner manual.



 NOTES

[illegible]

Vehicle Care

General Information

- Accessories and Modifications 9-1
- Vehicle Storage 9-2

Vehicle Checks

- Doing Your Own Service Work 9-2
- Fuel System Components 9-3

Wheels and Tires

- Tire Changing 9-5

Jump Starting

- Jump Starting 9-5

Towing

- Towing the Vehicle 9-5

Appearance Care

- Exterior Care 9-6

General Information

Accessories and Modifications

Adding accessories or making modifications to the vehicle, including to the CNG tank shields, could cause a malfunction or damage and would not be covered by the vehicle warranty. The CNG fuel tanks under the vehicle are protected by tank shields. If the vehicle has a CNG fuel tank in the cargo area, it is covered with a shield.

WARNING

To help avoid damage to the CNG tanks and to reduce the risk of explosion, tank shields must be present. Do not attach accessories, such as racks or bins to the shield. Do not drill, modify, or use the shield as a work surface, or use fire near the shield or tank.

If a CNG tank needs service or repair, have only a qualified technician perform the work. See Accessories and Modifications in the owner manual for more information.

Vehicle Storage

In addition to vehicle storage procedures outlined in the owner manual, the following should be done with the vehicle in the event it will not be driven for extended periods of time:

- The manual shutoff valve is on the inner side of the driver side frame rail halfway between the front and rear tires.

A label is on the outside of the vehicle above the manual shutoff valve. Do not remove this label.

Turn the lever one-quarter turn clockwise to turn off.

- If you store the vehicle indoors, it should be parked in a well-ventilated area. We recommend the installation of a natural gas leak detector at the highest point of the ceiling.
- After storing the vehicle for an extended period, and before starting the engine for the first time, open the doors and leave them open for several minutes. This allows any natural gas vapors that may have collected in the cargo area to dissipate.

Vehicle Checks

Doing Your Own Service Work

WARNING

Never try to do your own service work on the Compressed Natural Gas (CNG) fuel system. The CNG fuel system operates under high pressure. You can be injured and the vehicle can be damaged if you try to do your own service work. Service and repair of this system should only be performed by a qualified dealer.

Fuel System Components

WARNING

Tampering with, or improperly maintaining the high-pressure fuel system can cause a dangerous condition in which serious injury or death may result. Never attempt to modify the fuel system, and always have fuel system repaired and maintained by a qualified dealer.

CNG fuel system components include fuel tanks located in the cargo area and under the vehicle, an integrated fuel pressure regulator, in-tank fuel shutoff valves, high pressure fuel lines, electronically controlled multipoint fuel injectors, and other equipment.

Fuel system components comply with the appropriate safety standards. These component parts have been designed and approved for use in a CNG vehicle. Never modify or replace any original CNG components or parts with those specified for a gasoline-powered vehicle. Improper parts or components can damage the vehicle fuel system and affect the vehicle safety and performance.



Do not modify, tamper with, or perforate the cargo area tank shield. Damage to the fuel system can result.

Fuel Cutoff System

The in-tank fuel shutoff valve is controlled by the ignition switch. When the ignition switch is in the LOCK/OFF or ACC/ACCESSORY position, the valve is closed, shutting off fuel flow to the engine. It opens when the ignition switch is turned to the ON/RUN position. This also shuts off the high pressure solenoid on the high pressure regulator under the vehicle.

9-4 Vehicle Care

Manual Shutoff Valve



Locate the manual shutoff valve so that it can be found quickly if it is needed.

The manual shutoff valve is on the inner side of the driver side frame rail halfway between the front and rear tires.

A label is on the outside of the vehicle above the manual shutoff valve. Do not remove this label.

To turn off the valve, turn the lever one-quarter turn clockwise. Turn it counterclockwise to turn the valve back on.

Turn off the valve if a fuel leak is suspected or the vehicle is involved in an accident. This valve, when turned, will stop gas flow to the engine. If the vehicle has just been in storage and it will not start, verify that the valve is turned to the on position.

Wheels and Tires

Tire Changing

This vehicle does not have a spare tire. See *Towing the Vehicle* on page 9-5.

Jump Starting

WARNING

If the CNG fuel system has a leak, a spark from the jumper cables could ignite the natural gas, causing injury or death. Do not jump start the vehicle if you smell a persistent natural gas odor or hear a continual hissing sound. Close the manual shutoff valve, and have the vehicle towed to an authorized GM dealer for service. See *Fuel System Components* on page 9-3.

See “Jump Starting” in the vehicle owner manual.

Towing

Towing the Vehicle

WARNING

Improperly positioned tow straps, hooks, or chains can damage the CNG fuel system and cause a leak. If leaking gas catches fire, it could cause injury or death. To avoid damage, the disabled vehicle should be towed with all four wheels off the ground. Always flatbed on a car carrier.

See the owner manual for more information on towing the disabled vehicle.

Appearance Care

Exterior Care

Finish Damage



WARNING

Heating the vehicle to above 82°C (180°F) may cause the fuel pressure release device to open and release CNG gas. You could be injured or the vehicle could be damaged. Never cure a painted body repair by heating.

Service and Maintenance

Maintenance Schedule

Maintenance Schedule 10-1

Maintenance Records

Natural Gas Vehicle (CNG)
Service Records 10-3

Maintenance Schedule

WARNING

The tank shields protect the CNG tank in a crash and from road hazards. Removal of the shields may result in tank damage that could result in a rupture or possible explosion of the tank. You or others could be injured or even killed. If you must remove a tank shield for any reason, e.g., tank inspection or vehicle repair, always reinstall the shield before operating the vehicle.

WARNING

Keeping a CNG fuel tank in service after the tank service expiration date is dangerous and is prohibited by federal law. The tank may no longer withstand the CNG fuel system operating pressure. You could be severely injured or killed. Take the vehicle to an authorized GM dealer to have the tank replaced.

This CNG vehicle is designed for routine maintenance (fluids, filters, etc.) according to the original specifications as provided in the owner manual for gasoline fuel vehicles. See the owner manual for maintenance service intervals and fluid specifications.

10-2 Service and Maintenance

See your dealer or other qualified repair facility for required service and maintenance. Your dealer has the necessary training and parts to repair the vehicle.

In addition, the CNG system requires the following every 60 000 km (36,000 mi) or 36 months, whichever occurs first:

- Visual inspection of the CNG fuel tanks by a CSA International-certified inspector or authorized GM dealer. For more information, see your dealer or visit:

<http://www.csa-international.org>

Have the CNG fuel system and tanks inspected if the vehicle has been involved in a collision or fire. The fuel tanks must be replaced 15 years after manufacture. The expiration date of the fuel tanks is on a label on the fuel tanks. Have an authorized GM dealer replace the fuel tanks. Do not reuse old fuel tanks.

- Replacement of the coalescent filter. See your dealer.

Maintenance Records

Natural Gas Vehicle (CNG) Service Records

Vehicle Identification Number (VIN)

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

CNG Tank Information

Location	Size	Capacity	Serial #	Exp. Date
In Front Of Rear Axle	254 mm x 1 854 mm (10 in x 73 in)	79.5 L (21.0 gal)		
Behind Rear Axle (Front)	335 mm x 787 mm (13 in x 31 in)	51.0 L (13.5 gal)		
Behind Rear Axle (Rear)	335 mm x 813 mm (13 in x 32 in)	54.0 L (14.3 gal)		
Interior (If Equipped)	391 mm x 991 mm (15 in x 39 in)	90.0 L (23.8 gal)		

10-4 Service and Maintenance

CNG Fuel Tank Inspection Record

Tank Location:				
Tank Serial Number:			Tank Expiration Date:	
Inspection Interval (Mileage or Years)	Inspection Date	Inspector	Inspector Initials	Type of Repair
15 Years	N/A	N/A	N/A	Tank Exchanged

CNG Fuel Tank Inspection Record

Tank Location:				
Tank Serial Number:			Tank Expiration Date:	
Inspection Interval (Mileage or Years)	Inspection Date	Inspector	Inspector Initials	Type of Repair
15 Years	N/A	N/A	N/A	Tank Exchanged

10-6 Service and Maintenance

CNG Fuel Tank Inspection Record

Tank Location:				
Tank Serial Number:			Tank Expiration Date:	
Inspection Interval (Mileage or Years)	Inspection Date	Inspector	Inspector Initials	Type of Repair
15 Years	N/A	N/A	N/A	Tank Exchanged

CNG Fuel Tank Inspection Record

Tank Location:				
Tank Serial Number:			Tank Expiration Date:	
Inspection Interval (Mileage or Years)	Inspection Date	Inspector	Inspector Initials	Type of Repair
15 Years	N/A	N/A	N/A	Tank Exchanged



NOTES

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. There are no margins, text, or other markings on the paper.

Technical Data

Vehicle Data

Capacities and
Specifications 11-2

Vehicle Data

Capacities and Specifications

Application	Capacities	
	Metric	English
CNG Fuel Tank Capacity ^{1 2}	87.4L	23.1 GGE
¹ At 24.8 MPa (3,600 psi) and 21°C (70°F). ² GGE (Gasoline Gallon Equivalent)		

A

- Accessories and
Modifications 9-1
- Appearance Care
Exterior 9-6

B

- Battery
Jump Starting 9-5

C

- Canadian Vehicle Owners ii
- Capacities and
Specifications 11-2
- Check
Engine Light 4-2
- Cleaning
Exterior Care 9-6

D

- Driving
Vehicle Load Limits 8-1

E

- Engine
Check and Service Engine
Soon Light 4-2
- Starting 8-1

F

- Flat Tire
Changing 9-5
- Fuel 8-2
- Filling the Tank 8-3
- Gauge 4-1

G

- Gauges
Fuel 4-1

I

- Introduction ii

J

- Jump Starting 9-5

L

- Lamps
Malfunction Indicator 4-2

M

Malfunction Indicator Lamp 4-2

N

Natural Gas

Vehicle Service Records 10-3

Natural Gas Vehicle (CNG)

Service Records 10-3

S

Service

Accessories and

Modifications 9-1

Doing Your Own Work 9-2

Engine Soon Light 4-2

Service and Maintenance

Natural Gas Vehicle (CNG)

Service Records 10-3

Specifications and

Capacities 11-2

Starting the Engine 8-1

Storage

Vehicle 9-2

Supplement

Using iii

T

Tires

Changing 9-5

Towing

Trailer 8-7

Vehicle 9-5

Trailer

Towing 8-7

U

Using This Supplement iii

V

Vehicle

Canadian Owners ii

Load Limits 8-1

Towing 9-5

Vehicle Storage 9-2